

# Adapter

平成13年8月末現在

機 種 名	Ether 98-T
<b>NEC PC9821シリーズ</b>	
<b>MATE</b>	
PC-9821An/M2	95
PC-9821An/U2	95
PC-9821Ap2/M2	95
PC-9821Ap2/U2	95
<b>MATE X</b>	
PC-9821Xa7e/S15	95
PC-9821Xa7e/S17	95
PC-9821Xa10/C12	95
PC-9821Xa10/C4	95
PC-9821Xa12/C12	95
PC-9821Xa12/C8	95
PC-9821Xa13	95
PC-9821Xa16/R12	95
PC-9821Xa16/R16	95
PC-9821Xa16/W16	95
PC-9821Xa16/W30	95
PC-9821Xa20/W30	95
PC-9821Xa200/D30R	95
PC-9821Xa200/M30R	95
PC-9821Xa200/W30R	95
PC-9821Xt13/C12	95
PC-9821Xt13/K12	95
PC-9821Xv13/R16	98、95
<b>MATE R</b>	
PC-9821Rv 26/N20	NT
<b>MATE Pro</b>	
PC-9821St15/L16	98
<b>CanBe</b>	
PC-9821Cb model2	95
PC-9821Cb model2D	95
PC-9821Cb model2F	95
PC-9821Cs	98
PC-9821Cx3/S5T	95
PC-9821Cx3/S7M	95
<b>VALUESTAR</b>	
PC-9821V7/C4K	95
PC-9821V12/S5R	95
PC-9821V13/S5	95
PC-9821V16/S5	95
PC-9821V20/M7	98、95
PC-9821V166/S5	98
PC-9821V200/M7	95
PC-9821V233/M7D3	98