

USB

平成12年6月末現在

機種名	Ether USB-T
NEC	
VersaPro	
VA30H	98
VA36D/TX	98
LaVie NX	
LA500J/15D	98
LB20/40	98
LB26C/6	98
LB30C/7	98
LB400J/12	98
LT23/34	98
LT30D/54	98
LT36D/6	98
LW20/4	98
LW23D/53	98
LW30H/6	98
LW30H/7	98
LW33H/7	98
LW33D/7	98
LW40H/14	98
LW400D/84DA	98
LW450J/14CV	98
Mate NX	
MA26H	98
MA36H	98
MA55J	98
MA60J/CZ	98
MA70J	98
VALUESTAR NX	
VC23/4	98
VC26/4	98
VC30H/5	98
VC33/4	98
VC35D/6	98
VC45D/6	98
VC550J/7	98
VE36H/6	98
VE40H/7	98
VE46H/17C	98
VE450J/7	98
VE500J/7	98
VF26D/5	98
VF26D/6GC	98
VF26D/6GD	98
VF26D/6YC	98
VF26D/6YD	98
VM35D/4	98
VM45D/5	98
VM45J/6	98
VM550J/7	98
VT35D/6	98
VT35D/7C	98
VT35D/7D	98
VU45L/17	98
VALUESTAR NX R	
VR33L/6	98
VR400M/8	98
COMPAQ	
ARMADA	
1700	98
PREARIO	
1246	98
1919	98
1920	98
3580	98
5240	98
5270	98
DESKPRO	
EP C333/6.4	98
Gateway	
GP6-433C	98
GP7-450	98
Solo	
2500LS	98
3100XL	98
9100 233XL	98
9150LS	98
Panasonic	
Let's note	
CF-A1R	98
CF-C33J8C	98
CF-C33J8K	98
CF-M1V	98
CF-M32J8	98
SANYO	
WinkeyG1	
MBC-G1F	98

機種名	Ether USB-T
富士通	
FMV-BIBLO	
MC 23	98
MC 23	98
MC/30	98
MF 26	98
MF/33	98
NC 20	98
NC 23	98
NC 23	98
NE 20D	98
NE 23X	98
NE 26X	98
NE/36L	98
NR 30L	98
NR/33X	98
NS 23X	98
NS 26X	98
NU 23	98
FMV-DESKPOWER	
C 305	98
C 355	98
C/405	98
C/457	98
M 265	98
M 305	98
M 365	98
M/457	98
ME/35B	98
S 265	98
S 335	98
S 357	98
S 405c	98
T 357	98
T 457	98
FMV-DESKPOWER Pliche	
model220	98
model936T	98
IBM	
ThinkPad	
235 (2607-20J)	98
240 (2609-31J)	98
390 (2626-5AJ)	98
390 (2626-70J)	98
560X (2640-80J)	98
560Z (2640-9YJ)	98
560Z (2640-B0J)	98
600 (2645-53J)	98
770X (9549-71J)	98
ThinkPad i Series	
1424 (2621-42)	98
1455 (2611-455)	98
Aptiva	
E21 (2153-MZ7)	98
D1J (2156-1J5)	98
日立	
FLORA	
220	98
220CX	98
FLORA Prius note	
20J (202T23J)	98
20J (202T26J)	98
210 (2109T16G)	98
210 (210T13E)	98
220K (2204T26K)	98
270 (270T16E)	98
270 (270T20E)	98
270 (2702T23H)	98
270 (2703T23H)	98
FLORA Prius	
30 (30H20F)	98
30J	98
310 (3103ST30H)	98
310J	98
330 (3304ST33H)	98
330J (380N40JB)	98
SHARP	
Mebius	
MN-450-H23	98
MN-950-H33	98
PC-DJ50M	98
PC-FJ10	98
PC-FJ100R	98
PC-PJ1-98	98
PC-PJ1-M2	98
PC-PJ1-M3	98
Sofmap	
S	
ST450P3	98
ST5400C	98

機種名	Ether USB-T
SONY	
VAIO バイオノートXR	
PCG-XR1	98
PCG-XR1G	98
PCG-XR7	98
PCG-XR7S	98
VAIO バイオノート	
PCG-767	98
PCG-861/BP	98
PCG-862	98
PCG-864	98
PCG-868	98
PCG-887/BP	98
PCG-888	98
PCG-F16/BP	98
PCG-F23/BP	98
PCG-F50/BP	98
VAIO バイオノート505	
PCG-505GX/4G	98
PCG-505RX	98
PCG-505SX	98
PCG-505V/ABX	98
PCG-N505	98
PCG-N505AS	98
PCG-N505ES	98
PCG-Z505D	98
VAIO バイオC1	
PCG-C1	98
PCG-C1R	98
PCG-C1S	98
PCG-C1XF	98
VAIO バイオR	
PCV-R70	98
PCV-R71	98
VAIO バイオマイクロタワー	
PCV-S510	98
PCV-S520L3	98
PCV-S610	98
PCV-S710	98
VAIO バイオコンボ	
PCV-M350V5	98
PCV-M370V3	98
PCV-M370V5	98
PCV-M370V7	98
PCV-M390	98
VAIO バイオL	
PCV-L700/BP	98
PCV-L710/BP	98
SOTEC	
WinBook	
Quattro/X 300TX	98
PC BOOK	
333	98
Micro PC STATION	
300	98
333	98
366	98
366D	98
3500	98
PC STATION	
300S-L17	98
M250	98
康芝	
PX100	98
DynaBook	
2650	98
DynaBook Satellite	
4000X	98
4010X	98
4030X	98
4060X	98
4080X	98
DynaBook SS	
3300	98
3380V	98
7020X2	98
PORTEGE 6000	98
PORTEGE 7000	98
DynaBook TECRA	
8000	98
Dynatop	
6000	98
i COM	
COMPCHAMP	
CL-331DVD	98
MC2402	98
MC2462	98
MC2502	98
NC2402	98
P -502DVD	98
P -551DVD	98